

## HORIZON BOX

The **HORIZON BOX** option enables you to set and adjust basic functions of the Horizon box.

### POWER MANAGEMENT

The options available in **POWER MANAGEMENT** enable you to set the level of standby power and define standby usage:

**STANDBY POWER USAGE** Enables you to set the power level used when the Horizon box is in standby mode. The options are **HIGH**, **MEDIUM**, or **LOW**.



Please note that when the power usage is set to **LOW**, your Phone and Internet connection will be deactivated.

**AUTO STANDBY** Enables you to define when the Horizon box automatically switches to standby.

#### AUTOMATIC

The Horizon box switches to standby at the time set by you or after a set period of time.

#### OFF

AUTO STANDBY not in use.

#### AT NIGHT

The Horizon box switches to standby at the default time of 23:00. **AT NIGHT** standby finishes at a default time of 5:00. These times can be set using **DEFINE AUTO STANDBY TIME**.

**DEFINE AUTO STANDBY TIME** Enables you to set the start and end time of **AUTO STANDBY**.

**ACTIVATE STANDBY AFTER** enables you to set the period of time after which the Horizon box switches to standby. The time is set in increments of 30 minutes, from 30 minutes to a maximum of 240 minutes. The default is 210 minutes.

### SOFTWARE

Enables you to update the Horizon box system with the newest software and checks the version information of the currently installed system software.

### DIAGNOSTICS

The options available in **DIAGNOSTICS** enable you to review the status of various features of the Horizon box

### FACTORY RESET

Enables you to reset the Horizon box to the factory default settings with the possibility to keep or delete the recordings stored on the Horizon box disk.

### FRONT PANEL BRIGHTNESS

This option enables you to set the brightness of the Horizon box front panel display. The available setting levels are 25 %, 50 %, 75 % and 100 %, where 100 % is the maximum brightness.